

# SOFA TABLE

## Materials Needed:

1-22" x 44" Square Table Top  
(Waddell #3048A)  
4-28" Queen Anne Table Legs  
(Waddell #2728)  
4-Corner Plates  
(Waddell #2761)  
3-28" Skirting  
(Waddell #2735)  
1-Bag of Skirt Fasteners  
(Waddell #2762)

## Tools Needed:

Drill  
5/32" Drill Bit  
Phillipshead Screwdriver  
1/2" Wrench  
Sander  
Mitre Box & Saw

**Step 1:** Cut the **\*Skirts** to length. Cut a 1/4" deep slot 1" from each end of the **Skirts** according to the example shown

**Step 2:** Using a sander, chisel or router bit, cut a 45° chamfer approximately 3/8" wide along one corner of each **Table Leg**. This will become the inside corner of the **Table Leg**.

**Step 3:** It is easiest to build this **Table Top** upside down. Place the **Skirts** flat edge down on the bottom of the **Table Top** and assemble the **Skirts** and **Corner Brackets** by placing the **Corner Brackets** in the slots. Make sure that the **Corner Brackets** rest on the **Table Top** for accurate alignment. Mark and then pre-drill the holes for the wood screws. Finally, attach the **Corner Brackets** to the **Skirts** with the wood screws as shown.

**Step 4:** Place the **Table Legs** into the **Corner Brackets** and mark each **Table Leg** on the 45° chamfer through the bracket hole. Drill a 9/32" hole about 1-1/4" deep at the mark on each **Table Leg**.

**Step 5:** Next, using one of the 5/16" locknuts, screw a hanger bolt into each 9/32" hole. (NOTE: The locknut will thread all the way to the wood screw portion before you can actually screw the bolt into the leg. Keep screwing until the entire wood screw portion is in the **Table Leg**. Now, back off the locknut to remove it temporarily.

**Step 6:** Place each **Table Leg** into the skirt assembly and bolt together as shown replace the nut on the bolt and tighten securely.

**Step 7:** Place the four **Skirt Fasteners** in the middle of each **Skirt**. Be sure it faces the center of the **Table Top** and mark where to pre-drill the **Skirt** and the **Table Top**. Pre-drill each part carefully so the drill does not go through the table top. (For larger tables, two fasteners per side are recommended.)

**Step 8:** Apply desired finish to **Sofa Table**.

\*Suggested skirt lengths for Waddell Table Tops:

16" Round: 4, 6" long pieces

22" Round: 4, 10" long pieces

16" x 32" Oval: 2, 6.5" long & 2, 14" long pieces

22" x 44" Oval: 2, 10" long & 2, 22" long pieces

